

PC WIRELESS GAMING RECEIVER

Operating Instructions

Welcome

Thanks for choosing the PC Wireless Gaming Receiver, you can use a windows-based computer to enjoy the same kinds of wireless gaming experiences that you enjoy on your Xbox 360 console

NOTE: This product is designed for use on your personal computer, not on the Xbox 360 console

PC Wireless Gaming Receiver features

- Works with current and future Xbox 360 wireless accessories
- Uses integrated 2.4 gigahertz (GHz) high-performance wireless technology that lets you operate a wireless device from up to 30 feet away
- Lets you use up to four wireless controllers and four wireless headsets together with one wireless gaming receiver
- Connects to a powered USB 2.0 port on a computer
- Includes a six-foot USB cable

PC Wireless Gaming Receiver system requirements

- Operating system and processor
 - Windows XP with Service Pack 1, or later version of Windows
 - Pentium 300-megahertz (MHz) or faster processor
- Memory and storage
 - At least 128 megabytes (MB) of RAM
 - At least 150 MB of hard disk free space
- Ports
 - At least one available powered USB 2.0 port
- Other
 - Disc drive

PC Wireless Gaming Receiver package



The wireless Gaming Receiver package contains the following items:

- One PC Wireless Gaming Receiver
- One Setup disc for PC

Install the PC Gaming Receiver software on a computer

1. Before you connect the PC Gaming Receiver to the computer, insert the installation disc in the disc drive on the computer
2. Follow the steps in the wizard to install the software
3. Remove the green label from the USB connector on the PC Wireless Gaming Receiver

4. Insert the USB connector into an available powered USB 2.0 port on the computer




Note: The USB ports on the front of your computer are probably not powered USB 2.0 ports, Try using the ports on the back of your computer

5. When your USB connector inserted a dialog Pop up with the “Welcome to Found New Hardware Wizard” ,Then need select option “Install from a list or specific location(Advanced)”,click on button“Next”



6. Make sure the “Search for best driver in these locations” is selected and unselect “Search removable media”,Also select “Include this location in the search” ,Browse to “USB Driver” in CD folder,click on button “Next”



7. The “Completing the Found New Hardware Wizard” screen will appear and click on button “Finish”



Connect an Xbox 360 wireless accessory to the PC wireless Gaming Receiver

1. Turn on the Xbox 360 wireless accessory that you want to use with your receiver
2. Press and hold the connect button on the PC Wireless Gaming Receiver, The light flashes green
3. Press the connect button on the Xbox 360 wireless accessory, A green flashing light on the accessory and the receiver indicate that the device is trying to establish a connection, For example, if you are connecting the Xbox 360 wireless Controller, the Ring of Light will rotate as the device tries to connect



4. After the connection process is complete, the green light on the receiver and the accessory will stop flashing and remain illuminated, If you are connecting the Xbox 360 Wireless Controller, the light indicates the quadrant to which the accessory is connected

You cannot connect an Xbox 360 wireless accessory your Windows PC by using the PC Gaming Receiver, Try follow steps to resolve the problem

1. Verify that the accessory is an officially licensed Xbox 360 wireless accessory
2. Examine or replace the batteries to make sure that could interfere with the Xbox 360 wireless accessory
3. Move the receiver away from other devices that could interfere with the wireless communication between the receiver and the Xbox 360 wireless accessory
Note: Devices such as wireless routers, cordless telephones, and microwave ovens can generate wireless accessory
4. If the light on the receiver is not illuminated, examine the USB connection between the receiver and your computer, Make sure that the receiver is connected